

## In case of Leakage...

In case of leakage stop all operations, close all isolation valves - shout & raise alarm/siren.



In case of valve leakage from cylinder, put safety cap and take the cylinder in open space.



In case of body leakage, take the cylinder in open area & vent under controlled conditions.



Call Fire Brigade, *SUPER Gas* if leakage is not controlled.



Use D.C.P type fire extinguishers in case of fire and / or call Fire Brigade.



**In Emergency Dial**  
**Police: 100, Fire Brigade: 101**  
**Nearest *SUPER Gas* Office**